



C-4 Kick Down Cable kit 11-71011

Kit Parts List

42" ss sheath
67" inner cable with clevis
I bracket
kickdown bracket
allen wrench 5/32"

Hardware list

Tools needed

1/2" wrench

Installation Tips/pointers

To cut the cable , you will need to use cable cutting pliers.(Easiest way to identify cable cutting pliers is the 2 cutting surfaces.) If you do not have this type of tool, it is a little more hassle, but you can take the cable to Home Depot and use their cable cutters. When putting the cable into the housing or cable end, twist the cable clockwise as you are inserting to avoid fraying.
Carb Bracket: the part with 4 holes goes toward the firewall.

BC Broncos C4 Kick Down Cable

