

B.C. BRONCOS PLASTIC GLOVE BOX Installation

Please note that the B.C. Broncos plastic glove box liner CAN NOT be installed thru the dash panel opening. It can only be installed by following the instructions below.

PROCEDURE

1. Remove the old glove box. This can easily be done by removing the mounting screws, tearing and removing it thru the glove box opening. On later model Broncos, the fuse block is installed in the side of the glove box. Remove and retain the two screws and retaining ring. Save all the screws for mounting the new B.C. Broncos glove box liner.
2. Along the bottom edge of the dash, locate and remove the dash board mounting bolts. You will find two on the driver side (one holds the emergency brake) and one on the passenger side.
3. Gently pull the lower edge of the dash only enough to slide the B.C. Broncos glove box liner up past the heater and into place.
4. Locate the B.C. Broncos glove box liner over the opening and secure it with the screws.
5. On later model Broncos, position the fuse block and secure it with the retaining ring and screws.
6. Reinstall the three mounting bolts to secure the dash panel .