

FRONT WHEEL ALIGNMENT Instructions

Here's a quick and easy way to adjust your front wheel alignment. Park your Bronco on a flat, level surface, and use the method shown in the diagram below to measure the distance between

the tires at the front and at the rear. Adjust your toe-in so that the tires are 1/8" to 1/4" closer in the front than in the rear.

